


Start_częst: 1.548690 MHz; Stop_częst: 2.524446 MHz; Krok: 0.122 kHz

Próby: 7999; Przerwanie: 0 uS



no_label	SWR : 1.1475

Kursor 1:	SWR min : 1.04 1.852470
1.809770 MHz	SWR max : 17.39 2.038642
SWR : 1.1166	-----

Kursor 2:	
1.832950 MHz	
SWR : 1.0793	

Kursor 3:	
1.853080 MHz	
SWR : 1.0398	

Kursor 4:	
1.871624 MHz	
SWR : 1.0751	

Kursor 5:	
1.894926 MHz	